

BEAUTURAL

Curling Iron



1byone Products Inc.
1230 E Belmont Street, Ontario, CA 91761
Customer Service: +1 909-391-3888
www.1byone.com

Instruction Manual

IMPORTANT SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USING

KEEP AWAY FROM WATER

WARNING: This curling iron gets very hot when in operation, with serious risk of burns, electrocution, fire and injury.

Always follow basic safety precautions when using this curling iron, especially when children are present.

Safety Instructions When Connecting the Curling Iron to Power

- This curling iron complies with the recognized rules and pertinent safety regulations for electrical appliance.
- The power cable of this curling iron cannot be replaced. If the cable or the plug is damaged or has a defect, the curling iron should be discarded.
- Make sure the curling iron is turned off before connecting to power.
- The voltage of the power source must be the same as the specified voltage on the iron's ratings plate.
- Connect the curling iron only to AC current and to an outlet with grounding contact.
- Do not run the power cable over sharp edges and do not hang the iron from the cable. Instead the iron can be hung using the hanging loop.
- Keep the power cable away from extreme heat and moisture.
- Check that the curling iron is functioning properly before using. The curling iron should not be used if the power cable is damaged, if there is noticeable damage, or if it has been dropped.
- Never wrap the power cable around the curling iron.
- The power cable must not come into contact with the hot parts of the iron and should never run between the ironing rod and clip.
- Only insert the power plug into a power outlet when the iron is switched off.

Safety Instructions When Operating the Curling Iron

- This iron is very hot when in use. Do not let eyes and/or bare skin or heat-sensitive areas touch any hot parts or surfaces of the iron.
- The curling iron must not come into contact with flammable materials. The iron must also not be used near flammable materials as the iron can reach high temperatures of approximately 390°F.
- Never cover the curling iron with any other objects.
- Do not place or rest the iron on any surfaces while it is switched on.
- Remove the power plug from the power outlet after every use, before cleaning, and if the curling iron is not functioning properly.
- Do not pull on the power cable and do not carry the curling iron using the power cable.

Safety Instructions for Cleaning and Maintenance

- Always disconnect the curling iron from power and allow the iron to cool down before cleaning, performing maintenance, or if faults occur during operation.
- Do not pull on the power cable to remove the plug from the power outlet.
- Do not remove the power plug from the outlet with wet hands.


Risk of Electric Shock!

- If the power cable is damaged, it must be replaced by the manufacturer, service agent or similarly qualified personnel in order to avoid potential hazards.
- This curling iron may be used by children over 8 years old and by dependents if they are properly supervised and have been made fully aware of the risks of use. Children should not play with the curling iron. Cleaning and user maintenance should not be performed by children without supervision.
- Do not use this curling iron near bathtubs, showers, basins or other areas containing water.
- After use, or if pausing use for a significant length of time, unplug the iron from power and let it cool down completely before storing it.
- Protect the curling iron from moisture. Never put it into the dishwasher and never immerse it in water.

Risk of Burns with Hair Spray!

Do not use any sprays, styling agents and other inflammable chemical hair care products as hair sprays and styling agents may cause burning when coming into contact with the hot curling iron. This may cause significant damage to the hair and skin!

Product Description



1. Cool Touch Tip
2. Rod
3. Stand
4. Handle
5. Swivel Cable
6. Clip
7. Lever for Opening the Clip
8. LCD Display
9. Power On/Off Button
10. Temperature +/-
11. Hanging Loop
12. Glove

Included Items

- 1 x Curling Iron
- 1 x Glove
- 1 x Instruction Manual

Before using the curling iron for the first time, check the package contents to ensure all parts are free of visible damage.

Operating Instructions

1. Plug the curling iron into power and “OFF” will appear on the display screen.
2. Press and hold the Power ON/OFF button to turn on the curling iron. The display screen will show a default temperature of 320°F and the suitable hair type. The temperature reading will flash on the display until the set temperature is reached.
3. To select a temperature, press the +/- buttons until the desired temperature setting between 250°F and 390°F is reached. Press and hold the +/- buttons to increase or decrease the temperature more quickly.
4. It is recommended to select the lowest temperature setting (250°F) when using the curling iron for the first time and then raising the temperature if needed.
5. We recommend the following temperature settings:
 - Thin Hair: 250°F to 285°F
 - Normal Hair: 300°F to 340°F
 - Thick Hair: 355°F to 390°F

Warning!

Setting the temperature too high risks burning hair. If you are not sure of your hair type, begin using a lower temperature. A wrongly selected temperature or improper use of the curling iron puts your hair at risk of drying out or, in the worst case, burning.

Please Note:

A raising of temperature will be reached in just a few seconds, while a reduction in temperature will take effect more slowly.

Curling Hair

1. Section damp or dry hair evenly and comb through before styling.
2. Press the lever to open the clip and place hair strands between the rod and the clip.
3. Close the clip to hold the hair strands in place.
4. The ends of the hair strands can be shaped by twisting the curling iron either outward or inward before pulling it out over the ends.
5. Roll the hair up as far as you want it curled, being careful not to let the iron touch the scalp. Leave the curling iron in your hair for 5-8 seconds to achieve the desired curling results. For tighter, bouncier curls, roll less hair. For loose, free-flowing curls, roll more hair.
6. When you are finished styling, let your hair first cool down and do not comb or brush hair until it cools. Unplug and allow the iron to cool completely before storing it.

NOTE: Use the included glove to protect your hand from heat if necessary. Pay attention to use the correct side, wear it on left hand.

Preventing Accidental Operation

1. Double press the Power On/Off button to lock the curling iron. "Locking" means all buttons will stop functioning to prevent accidental presses.
2. Double press the Power On/Off button again to unlock.

Care and Maintenance

- This curling iron is intended for household use. Unplug the iron before cleaning. The iron must be cleaned only when cool.
- Use a soft non-abrasive cloth that is slightly dampened with water to wipe the curling iron surface. Do not allow water or any other liquids to enter the handle of the iron. Any other servicing should be performed by a qualified technician.
- The curling iron should not be stored while hot or plugged in. When not in use, allow the curling iron to cool down completely. It may then be put back in its box and store out of reach of children in a safe, dry location. Never wrap the cable around the curling iron; this could cause the cable to wear prematurely and break.

Specifications

Power Supply: AC 110V-240V~ 50/60Hz,
125W-112W
Temperature Range: 250°F to 390°F
Rod Length: 4.9"
Clip Length: 3.7"

Disposal

Disposal of the Product



Under no circumstances should you dispose of the product in normal domestic waste.

This product is subject to the provisions of European Directive 2012/19/EU.

Dispose of the product via an approved disposal company or your municipal waste facility. Please observe currently applicable regulations.

Please contact your waste disposal center if you need any further information.



The product's packaging is made from environmentally friendly material and can be disposed of at your local recycling plant.

**Customer Service/Kundenservice
Service Clients/Atención al cliente
Assistenza Clienti/カスタマーサービス**

US

To ensure speedy handling of your issue, please call or email us for assistance.

Phone: +1 909-391-3888

(Mon-Fri 9:00am - 6:00pm PST)

Email: ushelp@1byone.com

UK

To ensure speedy handling of your issue, please call or email us for assistance.

Phone: +44 158 241 2681

(Mon-Fri 9:00am - 6:00pm UTC)

Email: ukwebhelp@1byone.com

FR

Pour vous assurer une assistance rapide en cas de problème, veuillez envoyer un e-mail.

Email: euhelp@1byone.com

IT

Per supporto immediato in caso di bisogno, la invitiamo a contattarci via email.

Email: euhelp@1byone.com

CA

To ensure speedy handling of your issue, please email us for assistance.

Email: cahelp@1byone.com

DE

Für eine zügige Bearbeitung ihres Problems, melden Sie sich bei uns wie folgt.

Email: euhelp@1byone.com

ES

Para garantizar una rápida atención de su problema, favor envíenos un email para ayudarle.

Email: euhelp@1byone.com

JP

お客様の問題が直ちに解決されるため、ぜひメールにて弊社までご連絡ください。

Eメール: jphelp@1byone.com